

TIME POWER

50 K

70 K

90 K

115 K

160 K

Table of Content

Available models	2	Parameters to manage boiler	19
PCB configuration	3	Access to parameter setting menu	19
Spare PCB content	3	Parameter table (sort by number)	20
Installation	3	Display and INFO menu	22
Check list for first ignition	4	User views (general information on the display, for end user)	22
Gas conversion	5	Technical views (specific information for technicians)	22
User guide	5	Current Information	23
Accessing the main board	6	Settings	24
Boiler internal components	7	Alarms - errors	24
Models 50 K and 70 K	7	Last 5 errors log (for technician)	24
Models 90 K and 115 K	8	Errors list and description	25
Model 160 K	9	Plant bleeding function	26
Electric diagrams	10	Resistance value	26
Models 50 K and 70 K	10	Pump capacity diagram	27
Models 90 K and 115 K	11	Technical data	29
Model 160 K	12	Dimensions and connections	30
Power supply connections	13	Models 50 K -70 K	30
System control electric diagrams	14	Models 90 K -115 K	31
Filling the condensation collecting syphon	15	Models 160 K	32
Gas valve	15	Flue systems	33
Connectors and coils	15	Accessories	34
Gas valve adjustment - 50 K ... 115 K	15	Remote control	34
Gas valve adjustment - 160 K	16	External probe kit	34
Kits and operations for Gas Conversion	17	Outdoor Sensor kit and Remote Control	34
Models 50 K ... 115 K	17		
Model 160 K	18		


Available models

Model	Gas Type	Q input max	dimensions WxHxD	Weight
Time Power 50 K	G20/G31	47,5 kW	450 x 837 x 475	38,80 kg
Time Power 70 K	G20/G31	63 kW	450 x 837 x 475	45,80 kg
Time Power 90 K	G20/G31	85 kW	600 x 837 x 620	86,50 kg
Time Power 115 K	G20/G31	108 kW	600 x 837 x 620	92,00 kg
Time Power 160 K	G20/G31	150 kW	600 x 837 x 725	108,30 kg

Spare PCB content



- Nr. 1 Instruction sheet multi-language
- Nr. 1 PCB
- Nr. 1 Red wire jumper (mounted on M12 – pins 57-58)*

* Floor Thermostat contact for floor low temperature plant; E24 will appear if this contact will be open. Leave the jumper in, unless a normally-closed thermostat from the floor heating plant is connected in its place.





Installation

- Take off electric supply before opening control panel and replacing PCB
- Don't change micro-switches status (all OFF)
- Position P1: completely turned clockwise
Position P2: completely turned anticlockwise
- With 160 kW boiler, before closing the control panel, take note of the new PCB firmware for choosing the right action.




Power ON and find your boiler model in the table here below. In case follow instructions.

How to find the firmware




Boiler Model	Instructions
50 K	Change Par 0 into 2 , otherwise E32 will be showed
70 K	Change Par 0 into 3 , otherwise E32 will be showed
90 K	No actions are required
115 K	Change Par 0 into 5
160 K	Change Par 0 into 5 ONLY IF PCB firmware is K010D or precedent With G20 modify Par 13 = 150 and Par 14 = 740 With G31 modify Par 13 = 150 and Par 14 = 720

Enter menu parameters pressing together with boiler in OFF mode




Changing parameter number

Changing parameter value




Storing value

Check list for first ignition

Installation done under country regulation in force		
Flues and Air system	Verify that silicon gasket is correctly installed	
	No leakage between part of the system (extension, bends and flanges)	
	Avoid flues recirculation, respecting the minimum distances with split and concentric configurations	
Hydraulic plant	Correct plant pressure checked with cold system temperature	
	Ensure correct air bleeding	
	If present, check external tank connection according to its instruction provided with kit	
Gas plant	Check inlet pressure	
	Staticmbar	
	Dynamicmbar	
	Avoiding gas leakage from the gas connection on the boiler	
Electric connection	Check correct electric supply polarity and its values 230V (-15% +10%) - 50Hz	
	Check the correct 3way valve supply connection and replace the factory-installed resistor with tank probe provided in the kit	
	Remove the black electric plug already mounted and cable a plug suitable for your electrical supply	
Condense syphon	Fill syphon with water through the exhaust flues flange mounted on the top (adhesive on the metal cover)	
	Before discharging on the environment, connect to a waste water or treating its acidity with relevant products according to the local laws.	
Flues Test	Checking CO ₂ value	
	CO ₂ Qr%	
	CO ₂ Qn%	
	If CO ₂ values are not correct, do the procedure "Manual Calibration"	










Gas conversion

MOD.	HEAT INPUT	NATURAL GAS G20		COMMERCIAL PROPANE G31	
		CO ₂ at Qn and ignition (%)	CO ₂ at Qr (%)	CO ₂ at Qn and ignition (%)	CO ₂ at Qr (%)
50 K	Nominal value	9.3	8.9	10.3	9.8
	Allowed range	8.8 ... 9.8	8.4 ... 9.4	9.8 ... 10.8	9.3 ... 10.3
70 K	Nominal value	9.2	8.8	10.3	9.8
	Allowed range	8.7 ... 9.7	8.3 ... 9.3	9.8 ... 10.8	9.3 ... 10.3
90 K	Nominal value	9.2	8.8	10.3	9.8
	Allowed range	8.7 ... 9.7	8.3 ... 9.3	9.8 ... 10.8	9.3 ... 10.3
115 K	Nominal value	9.3	8.8	10.3	9.9
	Allowed range	8.8 ... 9.8	8.3 ... 9.3	9.8 ... 10.8	9.4 ... 10.4
160 K	Nominal value	9.3	9.0	10.2	9.6
	Allowed range	8.8 ... 9.8	8.5 ... 9.5	9.7 ... 10.7	9.1 ... 10.1

 In the case of liquid gas fuel, it is important that the boiler be exclusively fuelled with commercial Propane G31 and not with Butane G30. For this reason, we recommend that the supplier of the fuel be informed, for example, by applying a suitable warning on the gas tank or in its immediate vicinity, so that it is visible to the employee at the time it is being filled.




















User guide

The front control panel: PUSHBUTTONS

	Stand-by / Operating mode At each pressure, boiler switches cyclically from OFF mode to Summer and Winter operating modes. The present mode is indicated by the writing OFF , or through the simultaneous presence of the symbols  and  (Winter mode) or of the symbol  but not of the symbol  (Summer mode) or  (Only Heating mode).	Only if combined with domestic water boiler
	Heating adjustment They adjust heating system temperature. If External Probe Kit is installed, see also "External probe kit" on page 34.	
	Hot water setting: They adjust water temperature in domestic water storage (when this function is managed by the single boiler).	Only if combined with domestic water boiler
INFO	It shows on the display additional information related to boiler operation. (For details, see boiler's user instructions).	
RESET	Press it in order to restore boiler operation after a shut-down. See "Alarms - errors" on page 24 for details on possible shut-downs.	
plus	It manually sets activation and deactivation of the boiler quick preparation function.	Only if combined with domestic water boiler
	It activates automatic time programming of the boiler preparation function. It is used also in its programming and in the clock setting.	Only if combined with domestic water boiler

Accessing the main board

DISPLAY - symbols enabled in this model and their description


	CH – winter mode indication If flashing, it means that the boiler is functioning in CH mode. See also the remark in the description of symbol  .
	Burner ON It indicates the presence of the flame in the burner.
	DHW mode indication If flashing, it means that the boiler is functioning to produce hot water.
	If both  and  symbols flash at the same time, a Technician-reserved function has been activated. In this case, turn immediately the boiler off - and then turn it on again - by means of the button  .
	Two digit display under the symbol 
	Normally, it displays the CH flow temperature, i.e the temperature of the liquid on boiler's outlet that is sent to the CH system. During the CH temperature setting (by pressing the buttons  and ) , it shows the temperature value changing; in case of alarm it displays "E"; during the setting (reserved to the Technician) it displays the chosen parameter ID number
	Three digit display under the symbol 
	Normally, it displays the temperature of the hot water on boiler's outlet. When the boiler is in stand-by mode, it displays OFF . During the DHW temperature setting (by pressing the buttons  and ) , it shows the temperature value changing; in case of alarm it displays the ID number of the alarm; during the setting (reserved to the Technician) it displays the value of the chosen parameter.
RESET	It appears when the boiler is locked or anyway is present an error that the user could manage.
SERVICE	It appears when the boiler has detected an error (mainly a fault) that has to be managed by the Technician.
	It informs that the outdoor probe (accessories) is installed. Note: In this case the CH system temperature is automatically set and so the use of buttons  and  is different from the standard way: for deeper details rely on kit instruction and also "External probe kit" on page 34.


Accessing the main board

To access the management board


 **Cut power to the boiler.** Restore power supply only after having closed the dashboard back cover.

- Loosen the screws **1** and remove dashboard back cover.

 An incorrect or not complete closure of the electronic box voids the IP grade of protection of the appliance. Ensure that all closing items are correctly used and that all cables pass through the suitable slots. If one or more latches **2** should break, please use holes **3** with suitable screws (similar to the standard ones **1**).




Models 50 K and 70 K





- | | |
|--|---|
| 1 Fume exhaust connector (with connection point for combustion test) | 13 Gas valve compensation connection point |
| 2 Suction connector (with connection point for combustion test) | 14 Circulation pump automatic air purging valve |
| 3 Boiler automatic air purging valve | 15 Modulating circulation pump |
| 4 Combustion unit thermal fuse (connector) | 16 Gas valve |
| 5 Combustion unit air purging manual valve | 17 System pressure transducer |
| 6 Fume thermal fuse | 18 3-bar safety valve |
| 7 Ignition electrode | 19 Condensation-collecting siphon |
| 8 Suction hose | 20 System delivery temperature probe |
| 9 Discharge igniter | 21 Boiler safety thermostat (delivery) |
| 10 Mixer (air/gas mixing device) | 22 Detection electrode |
| 11 Motor-driven fan | 23 Combustion unit (burner + main exchanger) |
| 12 System return temperature probe | |

Models 90 K and 115 K



- | | |
|---|--|
| 1 Fume exhaust connector (with connection point for combustion test) | 12 Condensation-collecting siphon |
| 2 Suction connector (with connection point for combustion test) | 13 Mixer (air/gas mixing device) |
| 3 Boiler automatic air purging valve | 14 Gas valve compensation connection point |
| 4 Fume thermal fuse | 15 Gas valve |
| 5 Suction hose | 16 4.5-bar safety valve |
| 6 Boiler safety thermostat (delivery) | 17 System pressure transducer |
| 7 System return temperature probe | 18 Motor-driven fan |
| 8 System delivery temperature probe | 19 Discharge igniter |
| 9 Combustion unit thermal fuse (non-replaceable) | 20 Detection electrode |
| 10 Ignition electrode | 21 Combustion unit (burner + main exchanger) |
| 11 Modulating circulation pump | 22 Combustion unit thermostat (manually resettable) |

Model 160 K



- 1** Fume exhaust connector (with connection point for combustion test)
- 2** Suction connector (with connection point for combustion test)
- 3** Boiler automatic air purging valve
- 4** Fume thermal fuse
- 5** Suction hose
- 6** Boiler safety thermostat (delivery)
- 7** System return temperature probe
- 8** System delivery temperature probe
- 9** Combustion unit thermal fuse (non-replaceable)
- 10** Ignition electrode
- 11** Modulating circulation pump

- 12** Condensation-collecting siphon
- 13** Mixer (air/gas mixing device)
- 14** Gas valve compensation connection point
- 15** Gas valve
- 16** 4.5-bar safety valve
- 17** System pressure transducer
- 18** Motor-driven fan
- 19** Discharge igniter
- 20** Detection electrode
- 21** Combustion unit (burner + main exchanger)
- 22** Combustion unit thermostat (manually resettable)

- 4 Combustion unit thermal fuse (*)
- 5 Ignition electrode
- 7 Discharge igniter
- 8.1 Motor-driven fan - speed control
- 8.2 Motor-driven fan - power supply
- 11 System return temperature probe
- 12.1 Modulating circulation pump - speed control
- 12.2 Modulating circulation pump - power supply
- 18 Gas valve (opening control)
- 23 System pressure transducer
- 24 System delivery temperature probe
- 25 Boiler safety thermostat (delivery) (*)
- 27 Detection electrode
- 29 Fume thermal fuse (*)
- 30 Combustion unit thermostat (manual reset) (*)
- 60 Display board
- 61 F2A fuse (quick 2 A)
- 62 Control keyboard
- 63 2.2 kOhm - 1/2W (**) resistor
- 64 Power supply connector through safeties kit (**)(***)

- 65 Boiler connection terminal board
- 66 Terminal board for connection of VD by-pass valve kit (only models 50kW and 70kW) or PRS Domestic Water Booster Pump
- 67 Terminal board for PRR Heating Booster Pump control
- 68 Electric charges board


External components, optional:

- 70 **Ambient thermostat:** *Ambient Thermostat or Chronothermostat (available on the market) simple contact in very low SELV safety voltage. Closed contact = active request.*
- Remote control:** *terminals of the original remote control device, in compliance with the OPENTHERM protocol. To install, remove junction between the two conductors and connect to device terminals (extend if necessary)*
- 71 Preparation for area system kit with remote control
- 72 Preparation for underfloor heating system safety thermostat
- 73 Preparation for external probe kit
- 81 System temperature safety block thermostat (*) (**)(●)


- 82 Minimum pressure switch (*) (**)(●)
- 83 Maximum pressure switch (*) (**)(●)
- TA2 Preparation for differentiated temperature areas ambient thermostat
- TB Domestic water storage thermostat (*) (**)
- STB Sensor for domestic water storage temperature. *Included in the VD 3-way by-pass valve kit (**)*
- VD 3-way by-pass valve kit - (only models 50kW and 70kW) (**)
- PRR Heating Booster Pump *(foresee piloting relays)*
- PRS Domestic Water Booster Pump *(foresee piloting relays)*

(*) contacts of these components are shown in rest / cold position.
 (**) for details see "Power supply connections" on page 13
 (***) the complete (male+female) connector is supplied, to properly connect the boiler to power supply of single or cascade systems
 (●) Optional component, that can be required or not according to local or national regulations

Power supply connections




Remark: the contact of the minimum pressure switch 82 (normally open) is shown in rest condition, i.e. at no system pressure. In conditions of normal operation, the system has the correct pressure and also this contact will be closed.



Optional safeties wiring example

Refer to local/national regulation for the requirements of these devices.

If safety devices are **not** required, **don't forget to jumper terminals L1 and L2 together** in the connector 64 - power supply side (see diagram).




System control electric diagrams

- BK** Black
- BN** Brown
- BU** Blue
- GN** Green
- GY** Grey
- OG** Orange
- RD** Red
- VT** Violet
- WH** White
- YE** Yellow


50 kW and 70 kW models with Domestic Water Booster Pump (PRS) only

Set parameter **44** to the value **3**




90 kW and 115 kW models with Domestic Water Booster Pump (PRS) only

Set parameter **44** to the value **3**




Models 50 kW and 70 kW with Heating Booster Pump (PRR) only and possible domestic water By-Pass Valve (VD).

Set parameter **44** to value **0 - 1** or **2** according to needs




90 kW and 115 kW models with Heating Booster Pump (PRR) only

Set parameter **44** to value **0 - 1** or **2** according to needs




50 kW and 70 kW models with both Domestic Water (PRS) and Heating Booster Pumps (PRR)

Set parameter **44** to the value **3**




90 kW and 115 kW models with both Domestic Water (PRS) and Heating Booster Pumps (PRR)

Set parameter **44** to the value **3**




00224 INT 01

Filling the condensation collecting syphon


 During First installation of boiler or after long inactivity periods, **fill the condensate trap by pouring water** (about 1/2 litre) in the **flue OUTLET**, as shown in the picture.

 **Beware NOT to pour water in the inlet connection!**



Gas valve


Connectors and coils



Gas valve adjustment - 50 K ... 115 K

 Before checking combustion (except in case of first ignition), clean burner and exchanger.


For check (and, if necessary, for adjustment) a **correctly calibrated fume analyser** is needed (in condensation boilers measurement precision and correctness is particularly important). Therefore, through a dashboard function, we will ignite burner at low flow first and then at maximum flow and we will carry out measurements and adjustments in both conditions. Proceed as follows:

1. Boiler must be electrically powered and it must be set to **OFF**. Operate, if necessary, on key  (OFF shown on the display, at the bottom);
2. On the fume exhaust connector, unscrew fume analysis connection point screw, insert the analyser probe in the fume analysis connection point, ensuring connection waterproofness;

Note: Sensor located at the top of the probe should be located in a position as centred as possible of the exhaust flow: it is advisable to fully insert probe and then extract it by ca. 4 cm. Insert probe so that the probe protection bow, located at the top, is transversally located (the flow must flow through it and directly reach probe).

 Activate ambient Thermostat to generate a heat request and make sure that the heat produced by the boiler can be dissolved by radiators (and/or radiating panels / underfloor heating systems).

3. activate boiler **at minimum non-modulated power**, entering the technical menu and using the "Chimneysweeper" function which can be activated selecting parameter **12** and setting value **0** (see "Parameters to manage boiler" on page 19): burner ignites at low flow.




Gas valve

4. referring to the following table, verify that the numerical indicator at the bottom, in the middle of the display, shows the correct value for the **rpm at Qr** for the **type of gas used*** (*you are measuring fan rpm x 100 at low flow, for example, value 14 means that fan turns at 1400 rpm*);

Flow		Natural gas (G20)		Commercial propane G31	
		CO2 %	Fan rpm	CO2 %	Fan rpm
50 K	Reduced Qr	8.9 ±0.5	1200	9.8 ±0.5	1200
	Rated Qn	9.3 ±0.5	5500	10.3 ±0.5	5200
70 K	Reduced Qr	8.8 ±0.5	1200	9.8 ±0.5	1200
	Rated Qn	9.2 ±0.5	5500	10.3 ±0.5	5200
90 K	Reduced Qr	8.8 ±0.5	1200	9.8 ±0.5	1200
	Rated Qn	9.2 ±0.5	6100	10.3 ±0.5	5700
115 K	Reduced Qr	8.8 ±0.5	1200	9.9 ±0.5	1200
	Rated Qn	9.3 ±0.5	6700	10.3 ±0.5	6700

5. wait until boiler reaches normal conditions (ca. 5 minutes). If the **CO₂** value of fumes at a **Qr** low flow for the **type of used gas** is included in the interval shown in the table, go to point **6** for check / adjustment at rated flow, otherwise CO₂ must be brought back into correct values, modifying the off-set by turning the **P.R. screw. ADJ.** (adjustment screw is inside the bush, under the screw plug). **ATTENTION: turn screw by 1/8-turn at a time and wait 1 minute** to let the value of CO₂ measured by the analyser stabilise;
- if the **CO₂** value is **HIGHER** than allowed, **DECREASE** off-set by turning **P.R. screw. COUNTERCLOCKWISE ADJ.**;
 - if the **CO₂** value is **LOWER** than allowed, **INCREASE** off-set by turning **P.R. screw. CLOCKWISE ADJ.**;
6. without exiting the technical menu, activate boiler at **maximum non-modulated power**, setting the parameter **12** to value **1**;
7. burner ignites at rated flow. Wait until boiler reaches normal conditions (ca. 5 minutes). If the **CO₂** value in fumes at a **Qn** rated flow for the **type of used gas** is included in the values indicated in the table, exit the technical menu (boiler switches back to **OFF**), otherwise the gas flow rate must be adjusted turning the **R.Q. screw. ADJ.** . **ATTENTION: screw must be turned by 1/4 - 1/2-turn at a time**, and then it is necessary to wait 1 minute to let measured values stabilise:
- if the **CO₂** value is **HIGHER** than allowed, turn **R.Q. screw. CLOCKWISE ADJ.**;
 - if the **CO₂** value is **LOWER** than allowed, turn **R.Q. screw. COUNTERCLOCKWISE ADJ.**



Note: If you have adjusted CO₂ at rated flow, it is advisable to check again CO₂ value at reduced flow (points from 3 to 5.)

8. set parameter **12** to value **0**, then exit technical menu (see "Parameters to manage boiler" on page 19). Boiler switches back to OFF;

! IMPORTANT: after verification or adjustment it is ESSENTIAL:

- to close, on the gas valve, the **PINT** pressure connection point, by screwing relevant screw;
- close fume connection point repositioning closing block **2** and screw **1** making sure that the plastic flange surface is not damaged or worn;
- seal **PR** screw plug **ADJ.** and **R.Q. screw ADJ.** , if they have been used;
- verify the correct seal of the fume circuit, in particular the seal of the closing block **2**.

Gas valve adjustment - 160 K

- (i)** Before checking combustion (except in case of first ignition), clean burner and exchanger.

For check (and, if necessary, for adjustment) a **correctly calibrated fume analyser** is needed (in condensation boilers measurement precision and correctness is particularly important). Therefore, through a dashboard function, we will ignite burner at low flow first and then at maximum flow and we will carry out measurements and adjustments in both conditions. Proceed as follows:

1. Boiler must be electrically powered and it must be set to **OFF**. Operate, if necessary, on key **⏻** (OFF shown on the display, at the bottom);
2. On the fume exhaust connector, unscrew fume analysis connection point screw, insert the analyser probe in the fume analysis connection point, ensuring connection waterproofness;

Note: Sensor located at the top of the probe should be located in a position as centred as possible of the exhaust flow: it is advisable to fully insert probe and then extract it by ca. 4 cm. Insert probe so that the probe protection bow, located at the top, is transversally located (the flow must flow through it and directly reach probe).

- (i)** Activate ambient Thermostat to generate a heat request and make sure that the heat produced by the boiler can be dissolved by radiators (and/or radiating panels / underfloor heating systems).

3. activate boiler **at minimum non-modulated power**, entering the technical menu and using the "Chimneysweeper" function which can be activated selecting parameter **12** and setting value **0** (see "Parameters to manage boiler" on page 19): burner ignites at low flow.

4. referring to the following table, verify that the numerical indicator at the bottom, in the middle of the display, shows the correct value for the **rpm at Qr** for the **type of gas used*** (you are measuring fan rpm x 100 at low flow, for example, value 14 means that fan turns at 1400 rpm);

Flow		Natural gas (G20)		Commercial propane G31	
		CO2 %	Fan rpm	CO2 %	Fan rpm
160 K	Reduced Qr	9.0 ±0.5	1500	9.6 ±0.5	1500
	Rated Qn	9.3 ±0.5	7400	10.2 ±0.5	7200

5. wait until boiler reaches normal conditions (ca. 5 minutes). If the **CO₂** value of fumes at a **Qr** low flow for the **type of used gas** is included in the interval shown in the table, go to point **6** for check / adjustment at rated flow, otherwise CO₂ must be brought back into correct values, modifying the off-set by turning the screw. **1. ATTENTION: turn screw by 1/8-turn at a time and wait 1 minute** to let the value of CO₂ measured by the analyser stabilise;
- if the **CO₂** value is **HIGHER** than allowed, **DECREASE** off-set by turning the screw **1 COUNTERCLOCKWISE**;
 - if the **CO₂** value is **LOWER** than allowed, **INCREASE** off-set by turning the screw **1 CLOCKWISE**;
6. without exiting the technical menu, activate boiler at **maximum non-modulated power**, setting the parameter **12** to value **1**;
7. burner ignites at rated flow. Wait until boiler reaches normal conditions (ca. 5 minutes). If the **CO₂** value in fumes at a **Qn** rated flow for the **type of used gas** is included in the values indicated in the table, exit the technical menu (boiler switches back to **OFF**), otherwise the gas flow rate must be adjusted turning the **R.Q.** screw. **ADJ. ATTENTION: screw must be turned by 1/4 - 1/2-turn at a time**, and then it is necessary to wait 1 minute to let measured values stabilise:
- if the **CO₂** value is **HIGHER** than allowed, turn the screw **2 CLOCKWISE**;
 - if the **CO₂** value is **LOWER** than allowed, turn the screw **2 COUNTERCLOCKWISE**


Note: If you have adjusted CO₂ at rated flow, it is advisable to check again CO₂ value at reduced flow (points from 3 to 5.)

8. set parameter **12** to value **0**, the 4 exit technical menu (see "Parameters to manage boiler" on page 19). Boiler switches back to OFF;



IMPORTANT: after verification or adjustment it is ESSENTIAL:

- to close, on the gas valve, the **PINT** pressure connection point, by screwing relevant screw;
- close fume connection points by means of the relevant screw plugs;
- seal gas valve's screws **1** and/or **2**, if they have been used;
- verify the correct seal of the fume circuit, in particular the seal of the fume connection points.



Kits and operations for Gas Conversion

Models 50 K ... 115 K

Content


- 1 Mixer assembly
- 2 Gasket, 3/4", for the connection of the gas pipe to the gas valve.
- 3 Gasket, for the connection of the gas pipe to the mixer assembly:
 - 50 kW assembly: 3/4" (same as gasket 2)
 - 70 kW - 90 kW and 115 kW assembly: 1"
- 4 Gasket (O-ring) for the coupling of the mixer assembly to the fan
- 5 Label indicating the type of gas
- 6 Sticker for tank (only in kits for conversion to G31)

Kit installation



WARNING:


- Set parameter **PC 01** according to gas type: **0** for **Natural Gas (G20)**, **1** for **Propane (G31)**; for further information see the User Manual);
- Put the gas type sticker **5** close to the bottom of the WARNING label inside the boiler;



Kits and operations for Gas Conversion

- **Always replace every gasket;**
- Please note that boiler can only be supplied with **Propane G31**. **Using Butane G30 boiler could not work properly**. Therefore, put the sticker **6** on the gas tank or close to it, in order to be seen clearly while next gas supplying will occur;
- The adapter **7** is fitted on mixer assembly **1**. During gas conversion, check gasket **9** is correctly placed on its spot. The adapter must be fully inserted in the mixer assembly, therefore the slots **8** must match the two screw heads on the mixer.


- Other parts
- 7** Mixer/air pipe adapter
 - 8** Slots in the adapter
 - 9** Gasket of the adapter



Model 160 K

Content

- 1** Flat gasket for gas pipe - gas valve connection (1")
- 2** Diaphragm for gas valve (calibrated, with a diameter suitable for the target gas of the kit)
- 3** Gas type indication label
- 4** Tank sticker (only in G31 conversion kits)




Kit installation

⚠ CAUTION:

- Set the boiler parameter **PC 01** in accordance with the type of gas in use: **0** for **Methane (G20)**, **1** for **Propane (G31)**; see also the Installer / Technician section in the boiler instruction booklet);

⚠ Take off electricity and gas: from the boiler.

- apply the label indicating the type of gas **3** in the area provided on the plate "WARNINGS" of the boiler;



- **always replace all gaskets**, even the flat gasket **2** between the gas pipe and the gas valve;
- remove the gas valve **12** from the fan unit **16**, disconnecting the wiring from the connector, unscrewing the swivel nut fitting of the gas pipe **11** and finally unscrewing the 3 fixing screws **13**;
- from the gas valve outlet hole, remove the original diaphragm **15** complete with gasket/support **14** **by hand only**;

(i) **Do not use metal tools** or other objects inside the calibrated hole of the diaphragm (if it has irregularities, gas supply problems may arise)

- remove the diaphragm **15** from the gasket/support **14** and replace it with the diaphragm **2** supplied in the kit; reinsert everything in the gas valve outlet hole;


(i) The side of the diaphragm with the punched indication of the gauge must be facing the outside of the gas valve (i.e. towards the burner's fan)

- reassemble the gas valve **12** by replacing the gas gasket **1**, fix the gas valve from the fan assembly **16** using the 3 fixing screws **13**, tighten the swivel nut fitting **11** and reconnect the gas valve wiring.
- In case of supply from G20 to liquid gas, **it is important that the boiler is fed exclusively with commercial Propane G31 and not with Butane G30**. Therefore, to inform the fuel supplier about this, apply sticker **4** on the gas tank or in its immediate vicinity, so that it is clearly visible to the employee when refueling.

⚠ Restore the electricity and gas supply to the boiler;

check the absence of gas leaks;


test the correct combustion.



Parameters to manage boiler

Access to parameter setting menu

1. Boiler status: **OFF**
 - Push at the same time: **+ .III** and **+ F**
 - Keep on pushing **for 10 seconds** until **SERVICE** appears.
2. The number on the left shows the **# of parameter**. Scroll the parameter with **+ .III** or **- .III**
3. The number on the right shows **the value of the parameter**, Set the value with **+ F** or **- F**
4. To store changes, push **plus** for **3 seconds**
5. Exit function with button **power**



Parameters to manage boiler

Parameter table (sort by number)

Color Key Suggested to not modify

PAR	Boiler Config	Description	Values	Factory Setting	Note
00	All	Power of boiler (it is set by technician in production)	0 - 5	Based on type	0/1 - Not Used 2 - 50 kW 3 - 70 kW 4 - 90 kW 5 - 115 kW 6 - 160 kW
01	All	Type of gas	0 - 1	Based on type	0 - NG 1 - LPG
02	All	Temperature Range for CH demand	0 - 1	0	0 - Standard Range 35 ÷ 78 °C 1 - Low Range 20 ÷ 45 °C
03	All	Slow Ignition	---	25	50-70 kW = range 10-60 90-115 kW = range 10-40
04	All	Max power on CH demand	00 - 99	99	The value is a percentage of the maximum of gas valve
05	All	Functioning of pump on CH demand	0 - 2	0	0 - Standard working 1 - Pump always ON 2 - Pump always OFF
06	All	Delay of re-ignition boiler after SET reached	0 - 15	3	Minutes
07	All	Functions for bleeding hydraulic plant	0 - 3	0	0 - Functions OFF 1 - Bleeding plant on the Heating side 2 - Bleeding plant on the Sanitary side 3 - Bleeding plant on both side
09	All	Timing to reach the maximum power in CH demand	20 - 120	25	Seconds
10	All	Timing to reach the maximum on CH demand after switching OFF for high temperature	1 - 10	2	Minutes.
12	All	Chimney function (for service tests)	0 - 1	0	0 - Boiler ON at the min fan revolution 1 - Boiler ON at the max fan revolution
13	All	Min fan revolution *(Not advised changing)	110-300	Based on Gas	r.p.m x 10
14	All	Max fan revolution *(Not advised changing)	380-700	Based on Gas	r.p.m x 10

PAR	Boiler Config	Description	Values	Factory Setting	Note
15	All	Pre-Ventilation	15-60	30	Seconds
16	All	Post-Ventilation	10-60	20	Seconds
17	All	Temperature SET for TA2	0 / 20-80	0	0 - Input for Telephone controller 20 - 80 SET flow temp following demand from TA2
18	All	Showing fan revolutions	0 - 1	0	0 - Function DEACTIVATED 1 - Function ACTIVATED for 15min
19	All	Delay of switching ON, after CH demand	0 - 5	0	Minutes. It is used when there are zone-valves with long open time, on the plant.
20	All	Timing of pump functioning after CH demand	0 - 240	30	Seconds
21	Singular	Timing of pump functioning after DHW demand	0 - 240 tank	180 Tank	Seconds
22	All	Delay of operating time for ON error E24 (clacson low temp)	0 - 120	30	Seconds. Contact «TP» on the electric scheme
23	Singular	SET temperature of tank	0 30 - 60	0	0 - Settable by knob on control panel 30 - 60 temperature set by the technician and not settable anymore by the user
24	Singular	SET temperature of tank during the hourly tank preparation	0 20 - 50	40	0 - Tank not prepared 20 - 50 temperature SET Tank when hourly tank preparation function is OFF
25	Singular	ΔT for re-ignition boiler on tank preparation demand	1 - 10	3	ON burner for Tank demand = SET - (PAR25)°C
26	Singular	ΔT to get the max flow temperature during tank preparation	5 - 15	8	ΔT = SET Tank - T current. If ΔT > (PAR26): then T flow = max value
27	Singular	ΔT to set the min value of T flow on Tank preparation demand	5 - 20	15	T flow min = SET Tank + (PAR27)°C

PAR	Boiler Config	Description	Values	Factory setting	Note
28	Singular	Anti-legionella Function (ON/OFF)	0 50 - 70	60	0 – DEACTIVATED 50 – 70 Temperature of water during this function
29	Singular	Activation timing Anti-legionella, after not having reached Temperature at PAR 28	1 - 15	7	Days.
30	Singular	Duration of Anti-legionella function	0 - 30	1	Minutes.
31	All	Fan speed for fan/chimney flues validation test	0 - 99	99	The same for all power
32	All	Fan speed threshold to be reached for fan validation test	0 - 99	Based on boiler power	50 kW = 62 70 kW = 48 90 kW = 75 115 kW = 60 160 kW = 70
33	All	Modulating Pump Activation (only Heating demand)	0 - 2	0	0 – modulating disable 1 – modulating with ΔT fixed 2 – modulating with ΔT dynamic
34	All	Set the ΔT for modulating pump	0 - 3		0 – ΔT = 20°C 1 – ΔT = 15°C 2 – ΔT = 10°C 3 – ΔT = 5°C
35	All	Max modulating pump power	65 - 99	---	Linked to PAR 0, which sets this based on boiler power . It is NOT recommended to change this value
36	All	Set pressure values for loss of water switch	0 – 3	3	0 – Transducer not present 1 - OFF = 0,5bar, ON = 1bar 2 - (50-70 kW) OFF = 0,4bar, ON = 0,7bar 2 - (90-115 kW) OFF = 0,7bar, ON = 1,4bar 3 - OFF = 0,8bar, ON = 1,2bar


PAR	Boiler Config	Description	Values	Factory setting	Note
37	All	Type of plant filling-in *(not used in these models)	0 30 - 60	0	0 – Automatic From 30 to 60 litre of water inlet
38	All	Fan revolution during Post Ventilation	40-99	70	% of max fan revolution
39	All	External Temperature Correction	-5÷+5	0	Degrees (°C)
40	All	Booster function: Heating SET timing of increasing , until max SET.	0/ 1-60	0	If function activated, it increases Heating SET of +5°C. 0 = disabled 1-60 = Minutes;
41	All	Min Flow Temperature	20-50 20-35	---	If PAR 2 = 0 then range 20÷50; Default 35°C If PAR 2 = 1 then range 20÷35; Default 20°C
42	All	Switching OFF burner Temperature from SET	0-10	5	Degrees(°C)
43	All	Switching ON burner Temperature from SET	0-10	0	Degrees(°C)
44	All	Management of connector 67 on PCB for external heating pump	0-3	0	0 = Standard functioning (linked to heating demand) 1 = Always ON 2 = Only linked to demand from TA (not TA2) 3 = Linked to both Heating and DHW demands
45	All	Max timing of DHW demand	0/ 10-180	0	0 = disabled 10-180 sec = After this time of no-stop DHW demand, boiler gives precedence to heating demand.

User views (general information on the display, for end user)

What it shows:


Cyclical views containing some information, such as:

- ✔ Plant pressure
- ✔ External temperature (if external probe is present)
- ✔ Current clock (if regulated before)



How to activate:

During normal functioning pressing briefly INFO button, User Views are showed:




Technical views (specific information for technicians)

What it shows:


Cyclical views containing some information, such as:

- ✔ Current Information
- ✔ Settings
- ✔ External Probe information (if present)



How to activate:

During normal functioning pressing for 5 sec. INFO button, Technical views are showed:



Current Information

Current functioning sequence of boiler
*see table at the bottom

	If present : CH mode enabled If flashing : CH demand ON 1-2: TA on demand
	If present : Solar PCB connected If flashing : Solar Pump ON
	If present : PLUS function enabled If flashing : PLUS function ON
	If present : DHW mode enabled If flashing : DHW demand ON


Current flow temperature → 61
Percentage of burner power → %99
Return NTC probe (only condensing models) → 50°C
Current DHW temperature → 54

N°	Ignition Step	Description
	NO DEMAND IN PROGRESS	NO demand in progress
1	STARTING CHECK CYCLE	Fan Minimum Revolutions control
2	START FAN CYCLE	Fan ON, checking fan revolution (NO flame yet)
3	BURNER CYCLE:	Gas valve open and sparking but NO flame yet
4	NO DETECTION FLAME	Timing for detection flame is over: waiting for new ignition attempt
5	DETECTION FLAME DONE	Slow ignition is running
6	MODULATION CYCLE	Calibration of gas quantity burned according to kind of demand
7	ENDING CYCLE	Gas Valve OFF, post circulation and post ventilation

Alarms - errors

Settings

Current CH SET point for TA1 or gradient curve External probe SET



Current DHW SETpoint

Current CH SET point for TA2

NOT USED in this configuration


Alarms - errors

Last 5 errors log (for technician)

This function allows technician to obtain information about errors occurred on boiler.

What it shows:

Cyclical views containing last 5 errors detected:



How to activate this function?

1. When boiler is in **OFF** mode, pushing **for 6 sec** button **INFO**, the "Last 5 errors" function is enabled.
2. Pushing buttons **+|||** and **-|||** to scroll errors occurred.
3. Pushing buttons **+F** and **-F** to scroll pages information about single error.



Errors list and description

Error code	Kind of error	Description
E 01	RESET	No flame detected.
E 02	RESET	High temperature on primary side.
E 03	RESET	Thermofuse contact is open.
E 05	SERVICE	CH flow probe value is out of range.
E 08	RESET	Flame lost 5 times after detection
E 10	SERVICE	Low pressure on the plant
E 12	SERVICE	Tank probe value is out of range.
E 15	RESET	Return probe value is out of range.
E 16	RESET	N° of fan revolutions is not corrected for functioning.
E 24	RESET	Low temperature plant thermostat is open.
E 29	RESET	Possible obstruction on flues pipes or chimney flues
E 31	SERVICE	Communication between PCB and remote control is not correct.
E 35	RESET	Flame detection with Burner ON.
E 38	SERVICE	External probe value is out of range.
E 39	SERVICE	Anti-freeze function: when boiler is switched ON and 1 probe feels 0°C, than no burner ON.
E 43	SERVICE	Return probe has felt high temp for more than 10 sec.
E 62	SERVICE	No communication between Display and main PCB.
E 91	SERVICE	No communication between pressure transducer and main PCB.
E 92	SERVICE	Overpressure detected by transducer.

Plant bleeding function

How it works:

Activating this function, the boiler starts a cycle of plant bleeding in order to help technician to fill-in water in a better way.

Different bleeding options based on plant requirements:

1. only the CH side of plant
2. only the DHW side of plant
3. both CH and DHW sides

Every cycle takes 2 minutes and it is composed by:

- For 1':30'' Pump ON
- For 30'' Pump OFF.

Entire function (7 bleeding cycle repeated) takes about 15min, unless leaving manually the function before.



How to activate:

Parameter n°7




PAR	Description	Values	Factory setting	Note
07	Functions for bleeding hydraulic plant	0 - 3	0	0 - Functions OFF 1 - Bleeding plant on the Heating side 2 - Bleeding plant on the Sanitary side 3 - Bleeding plant on both side

Resistance value

Contact β 3977	
°C	Ω
0	33000
20	12500
40	5350
60	2500
80	1260
100	700



Pump capacity diagram




TECHNICAL SPECIFICATIONS	Unit of meas.	Time Power 50 K		Time Power 70 K		Time Power 90 K		Time Power 115 K		Time Power 160 K	
		G20	G31	G20	G31	G20	G31	G20	G31	G20	G31
EC Certificate	Reference gas	0476 CQ 1281		0476 CQ 1281		0476 CQ 1281		0476 CQ 1281		0476 CQ 1281	
Category		II _{2H3P}		II _{2H3P}		II _{2H3P}		II _{2H3P}		II _{2H3P}	
Type		B23P - C13 - C33 - C43 - C53 - C63 - C83 - C93									
Operation temperature (min÷max)	°C	0 ÷ +60		0 ÷ +60		0 ÷ +60		0 ÷ +60		0 ÷ +60	
Maximum Power Input Q _n	kW	47.5	47.5	63.0	63.0	85.0	85.0	108.0	108.0	150.0	150.0
Minimum Power Input Q _r	kW	5.0	6.0	7.0	8.0	9.5	10.0	11.0	12.0	25.0	25.0
Maximum Power Output 60°/80°C *	kW	46.0	46.0	61.1	61.1	82.4	82.4	104.9	104.9	144.6	144.6
Minimum Power Output 60°/80°C *	kW	4.7	5.6	6.6	6.6	9.0	9.5	10.5	11.4	23.8	23.8
Maximum Power Output 30°/50°C *	kW	49.2	49.2	65.6	65.6	89.3	89.3	113.5	113.5	157.50	157.50
Minimum Power Output 30°/50°C *	kW	5.2	6.2	7.3	7.3	9.8	10.3	11.4	12.4	27.0	27.0
NO _x Class		6	6	6	6	6	6	6	6	6	6
Correct CO 0% O ₂ (at Q _n)	ppm	157.3	146.3	146.0	172.9	152.6	133.0	176.1	166.3	176.1	141.0
CO ₂ (at Q _n)	%	9.3	10.3	9.2	10.3	9.2	10.30	9.3	10.30	9.3	10.2
Condensation q.ty at Q _n (at 30°/50°C *)	l/h	4.4	4.4	6.5	6.5	9.3	9.3	12.4	12.4	18.40	18.40
Condensation q.ty at Q _r (at 30°/50°C *)	l/h	0.6	0.6	0.7	0.7	1.1	1.1	1.3	1.3	2.90	2.90
Condensation pH value	pH	2.8	2.8	2.8	2.8	2.8	2.8	2.8	2.8	2.8	2.8
Fume temperature at Q _n	°C	83.0	83.0	82.0	82.0	71.9	71.9	75.0	75.0	79.7	62.3
Fume mass flow (at 60/80°C * at Q _n)	kg/h	75.95	77.87	101.78	103.28	137.32	137.57	170.48	174.79	240.63	249.01
MEASURED EFFICIENCY *											
Nominal efficiency (NCV) at 60°/80°C	%	96.1		97.1		97.3		97.2		97.8	
Nominal efficiency (NCV) at 30°/50°C	%	103.5		104.1		105.0		105.1		105.0	
Efficiency at 30% load Q _a (NCV) at 30°C	%	106.7		107.2		109.1		109.1		109.3	
* return temperature / flow temperature; NCV = Net Calorific Value (=Hi) values are related to Average Power Output Q _a for Range Rated appliances											
HEATING DATA											
Temperature selection range (min÷max) in main zone, with range at normal / low temperature	°C	35÷78 / 20÷45									
Temperature selection range (min÷max) secondary zone	°C	20÷78									
Characteristics of water (or of thermal fluid) of heating system (* = if there are aluminium parts along the heating system)	°f pH	5 ÷ 15 °f pH 7.5 ÷ 9.5 (7.5 ÷ 8.5 *)									
Expansion tank	l	none (to foresee on the system, by the installer)									
Maximum working pressure	bar	3		3		4.5		4.5		4.5	
Boiler water content	l	3.5		4.0		9.0		11.5		14.0	
Max temperature	°C	95		95		95		95		95	
Boiler anti-freeze function temper. on / off	°C	5 / 30		5 / 30		5 / 30		5 / 30		5 / 30	
DOMESTIC WATER DATA											
Temperature selection range (min÷max)	°C	30÷60		30÷60		30÷60		30÷60		30÷60	
ELECTRIC CHARACTERISTICS											
Voltage/Frequency (rated voltage)	V / Hz	220÷240 / 50 (230V)		220÷240 / 50 (230V)		220÷240 / 50 (230V)		220÷240 / 50 (230V)		220÷240 / 50 (230V)	
Power (max)	W	145		190		255		315		480	
Protection rating		IP X5D		IP X5D		IP X5D		IP X5D		IP X5D	
DIMENSIONAL CHARACTERISTICS											
Length - Height - Depth	mm	see "Dimensions and connections" on page 30									
Weight	kg	39.4 / 43.5		45.8 / 49.9		86.7 / 92.4		91.5 / 97.2		108.3 / 114.4	
CONNECTIONS											
Gas and hydraulic connections		see "Dimensions and connections" on page 30									
Flue fitting: types, lengths, diameters		see "Flue systems" on page 33									
Min÷max fan residual head (for type C ₆₃)	Pa	25 ÷ 180		50 ÷ 280		10 ÷ 150		15 ÷ 165		25 ÷ 190	
GAS POWER SUPPLY PRESSURES											
Rated pressure	mbar	20	37	20	37	20	37	20	37	20	37
Pressure at input (min÷max)	mbar	17÷25	35÷40	17÷25	35÷40	17÷25	35÷40	17÷25	35÷40	17÷25	35÷40
Number of nozzles (Mixer group)		2	2	2	2	2	2	2	2	—	—
Diameter of nozzles (Mixer group) (*=open/close)	mm/100	460	345	740 / 570 *	470	640 / 560 *	480 / 440 *	640	520	—	—
GAS CONSUMPTION											
at Q _n	m ³ /h	5.02		6.66		8.99		11.42		15.86	
	kg/h	3.68		4.88		6.59		8.37		11.63	
at Q _r	m ³ /h	0.53		0.74		1.00		1.16		2.64	
	kg/h	0.47		0.62		0.78		0.93		1.94	


Dimensions and connections

(i) ATTENTION! Remove all the plastic caps placed to close the hydraulic connections and the condense outlet hose of the boiler


Models 50 K -70 K




Models 90 K -115 K




Models 160 K



Separate system (C₄₃, C₅₃, C₆₃, C₈₃, C₉₃ *)



System with suction from room (B_{23P})



Mod.	Separate system Ø80 mm original***	
	IN+OUT min÷max (m)	OUT max (m)
50 K	2 ÷ 30	25
70 K	2 ÷ 30	25

Mod.	System B _{23P} Ø80 mm original***	
	OUT max (m)	
50 K	1 ÷ 25	
70 K	1 ÷ 25	

Mod.	Separate system Ø100 mm original***	
	IN+OUT min÷max (m)	OUT max (m)
90 K	2 ÷ 30	29
115 K	2 ÷ 20	19
160 K	2 ÷ 20	19

Mod.	System B _{23P} Ø100 mm original***	
	OUT max (m)	
90 K	1 ÷ 29	
115 K	1 ÷ 19	
160 K	1 ÷ 19	

* Note: With the separate system it is possible to create also systems of type C₁₃ and C₃₃.

** Duct axis measurements are referred to the boiler upper profile and immediately to the entry of the first right-angle curve. Differences in levels due to slopes are not considered.

*** IMPORTANT: table is referred to original flue fitting accessories. When using NON-original flue fitting accessories (certified for condensation, the use of which is allowed by the special approval of C6 boilers) refer to the relevant technical documentation.


Coaxial system (C₁₃, C₃₃)

Mod.	Coaxial system Ø80/125 mm original***	
	Horizontal (THL) max (m)	Vertical (TVL) max (m)
50 K	8	10
70 K	8	10

Mod.	Coaxial system Ø100/150 mm original***	
	Horizontal (THL) max (m)	Vertical (TVL) max (m)
90 K	5	6
115 K	5	6
160 K	5	6

THL Total Horizontal Length

TVL Total Vertical Length



Remote control

This remote control **is more than a simple room thermostat**. Thanks to this, it is possible to **manage the boiler in all its settings** like DHW and CH temperature adjustment, **boiler reset** in case of boiler block, and of course it works as a **room thermostat** both in **manual** and **weekly program mode**. It's powered by the boiler (in safety low voltage), so **it doesn't need batteries**.

(i) Remove Remote Control from its box and **keep relevant instructions for use. Attach them to this instruction booklet.**



Neither the Remote Control nor the relevant cable coming from the boiler must be connected to the 230 V power supply, for no reason.

(i) **Cable maximum length must be less than 50 m.** In order to avoid malfunctions caused by disturbances, Remote Control connections and other possible low voltage connections must be kept separated from power supply system cables, e.g. letting them pass through separate sheaths.

1. Make sure that boiler is not electrically powered;
2. install device as described in **paragraph 1** of the booklet supplied with the Kit;
3. connect Remote Control connections **"OT" nr. 1-2** to the "TA - Room Thermostat - Remote Control" cable coming from the boiler using a suitable bipolar terminal. See also "Electric diagrams" on page 10;

Note: Remote Control connection has no polarity.

4. power supply the boiler and select the **Summer** mode;
5. check the correct work of the device. The electronics should recognize it automatically.

(i) Hereafter, the boiler should be left on **Summer mode; the boiler work is managed by the Remote Control, including the OFF, Summer and Winter modes, and the technical functions (such as several additional functions).**

In case of problems in wirings or in boiler setting, the alarm E31 will appear. See E31 alarm description on page 25.




External probe kit

The Outdoor Sensor manages automatically the CH flow temperature** as a function of the outdoor temperature, thus avoiding the user to adjust it manually. This function is also named "shifting temperature".

** that's the temperature of the heating elements. Don't mistake it with the room temperature (managed by the room thermostat or by the Remote Control, but not by the boiler) that doesn't depend on the first one.

The installation must be made by a professionally skilled technician following the instructions supplied with the kit. Refer to "Electric diagrams" on page 10 for the links to the Main Board.

After the installation of the Sensor, the buttons **+ .|||** and **- .|||** won't adjust directly the CH flow temperature, but the dispersion factor "kd" that's the response of the outdoor temperature, detected by the sensor, on the CH flow temperature, as shown in the following graph.



Because of the wide buildings typologies, it's impossible to give precise indications on kd value to set. The correct setting must be determined case by case and will have, as a result, an optimal comfort in all the climatic conditions requiring heating, i.e. a prompt reaching of the room temperature with cold weather and no room overheating during mild periods.

Practically, kd value should be adjusted depending on the estimated efficiency of the building's thermal insulation. Its range is from 01 to 30: use higher values when there is a high thermal dispersion and therefore a less efficient insulation (and vice versa).

Outdoor Sensor kit and Remote Control

If also the Remote Control Kit is installed, please refer to the relevant instruction handbook for details about the combined working of Outdoor Sensor and Remote Control itself.

www.italtherm.it



SERVICE TIME-POWER-K 20210210 - 20210217
ITALTHERM S.p.A. declines any responsibility for eventual printing and/or transcription errors in the present manual. In order to constantly improve its products, the company has the right to change features and data written in the present manual, at any time and without notice.